
Llegrand


adaptable DLP trunking 65 x 220 trunking and fittings







Selection chart (p. 706) Wiring capacity chart (p. 726)



2 comp. Cover 65 Cover 130 3 comp. Cover 65 Α В 106 07 106 58 5

Angles and end cap

Internal and external angles

Include the 2 components for the top and bottom of the trunking on which the flexible cover and 1 and 2 partition joints fit respectively, ensuring continuity of the partitions and holding the covers in place, for 2 and 3 compartment configurations

Changeable internal angle, from 85 to 95° for 65 x 150/65 x 195 and 65 x 220 mm trunkings Changeable internal angle, from 85° to 95° for 65 x 195 and 65 x 220 mm trunkings

Angles and end cap (continued) 3 comp. Cover 65

	Cover 130	В	
5	106 36		Changeable external angle, from 60° to 120° for 65 x 150/65 x 195 and 65 x 220 mm trunkings
5		106 39	Changeable external angle, from 60° to 120° for 65 x 195 and 65 x 220 mm trunkings
			Flat angle
2	107 96		90° flat angle
			End cap

			Junctions
	2 comp. Cover 65 Cover 130	3 comp. Cover 65	Flat junction
5		33	To ta
5	107	7 38	trun To ta trun cove
5	107	' 64	Angled junction To to 35 x 50 x

107 08

2 comp. Cover 65

ip. 65	Flat junctions				
		To tap-off to an 80 mm wide trunking			
		To tap-off to a 105 mm wide trunking equipped with a 50 mm cover			
	Angled junction				
		To tap-off in an internal angle to 35 x 105, 50 x 105, 35 x 80 and 50 x 80			
		For use with internal angles Cat.Nos 106 07/58			

Left or right end cap

50 50	2 comp. Cover 65 Cover 130 A 106	
100	308 81	

Accessories

Clip for 65 mm cover Clip for 130 mm cover Base for clamp

Installation accessories (p. 724)